
MANUAL FOR MOD-0007-TCP

AUTRONIK

TECHNICAL SPECIFICATIONS

Network Specifications				
Network interface	Ethernet 10/100Base-T			
Protocol	Modbus TCP			
Digital Inputs				
Channels	8			
Input Voltage	10-30V			
Sample Time	100 KHz			
Digital Outputs				
Channels	8			
Type	Sourcing			
Load Current	0.6A			
Output Voltage	24VDC			
Power Supply				
Power Supply Voltage	10-30VDC			
Current Consumption	350mA			

WIRING DIAGRAMS





MODBUS REGISTERS

MODBUS REGISTERS				
REGISTER	DECIMAL	DESCRIPTION	ACCESS	
0x00B0	176	Node ID	RO	
0x00B1	177	Power UP	RO	
0x00B2	178	Digital Outputs	R/W	
0x00B3	179	Digital Inputs	R/W	
0x00A0	160	Input 1	RO	
0x00A1	161	Input 2	RO	
0x00A2	162	Input 3	RO	
0x00A3	163	Input 4	RO	
0x00A4	164	Input 5	RO	
0x00A5	165	Input 6	RO	
0x00A6	166	Input 7	RO	
0x00A7	167	Input8	RO	
0x00C0	192	Output 1	R/W	
0x00C1	193	Output 2	R/W	
0x00C2	194	Output 3	R/W	
0x00C3	195	Output 4	R/W	
0x00C4	196	Output 5	R/W	
0x00C5	197	Output 6	R/W	
0x00C6	198	Output 7	R/W	
0x00C7	199	Output 8	R/W	

176: Node ID :

Contains the Modbus address of the device.

■ 177 : Power Up Status:

When this register is set to 1 the outputs of this device are closed at power up, when set to 0 (Default) the outputs are open.

• 178 : Digital Outputs:

This register allows control of all outputs at once. Each bit is an output.

■ 179 : Digital Inputs:

This register allows control of all inputs at once. Each bit is an input.

■ 160 – 167 : Inputs:

Gives the status of the corresponding input number.

• 192-199: Outputs:

Set this register to 0 or 1 to close or open its corresponding output number.

WEB SERVER

This device includes a web server in order to check or modify the status of its inputs and outputs.

The web server also allows the user to modify the network settings required for the device communication.

The default Network configurations are as follows:

- IP Address: 192.168.1.100
- Modbus Address: 1
- By default the device has the DHCP enabled, this means that if available the IP Adddress is given by the DHCP server.



WEB SERVER: DIGITAL INPUTS


The digital inputs page allows the user to read the inputs of the device. When clicked in the "READ" Button the server samples the inputs of the device once and displays its status., when clicked in "CONTINOUS READING" the server samples the inputs continously until the user clicks in the "STOP" button.

AUTRONIK					
MOD-0004-TCP					
STATUS					
Digital Input 0					
Digital Input 1	•				
Digital Input 2	•				
Digital Input 3	•				
Digital Input 4	•				
Digital Input 5	•				
Digital Input 6	•				
Digital Input 7	•				
READ	CONTINOUS READING	STOP			



WEB SERVER: DIGITAL OUTPUTS

The digital outputs page allows the user to close or open each digital output in the device. In order to modify the status of each output click on the corresponding output switch button and then click on the "UPDATE" button.





WEB SERVER: NETWORK SETTINGS

The network settings page allows the user to modify the communications configuration for the device. In order to modify a setting the user needs to modify the corresponding setting and then click on the "SAVE" button(The web browser may need to be restarted in order for the changes to apply.

AUTRONIK				
MDD-0001-TCP				
Network Settings	IP Address			
	Subnet Mask			
Digital Inputs	Gateway Mask			
Digital Outputs	MAC Address			
	Device Name			
	Enable DHCP	•		
		SAVE	l	



MECHANICAL DIMENSIONS

